

E300



| | | | | |
|---|---------|---|--|--|
| 1 | Z32CNM | E300N top-shell black | | |
| 2 | Z29FNM | E280 - E300N - E300B bottom-shell black | | |
| 3 | Z1732SR | Central reflector for E300N | | |
| 4 | Z314NM | Hinge black climbed on | | |
| 5 | Z140R | Lock key, 1 pcs. | | |
| 6 | Z310 | Bolt | | |
| 7 | Z112R | Red pulley, 4 pcs. | | |
| 8 | Z115R | Stop bag opening yarn, 2 pcs. | | |

| | | | | |
|----|--------|----------------------------|--|--|
| 9 | Z195 | Pin D. 04x80 mm | | |
| 10 | Z191R | Push button spring, 1 pcs. | | |
| 11 | Z315 | Push button | | |
| 12 | Z193 | Hinge pin 62 mm | | |
| 13 | Z312 | Hinge plate | | |
| 14 | Z236 | Hinge spring | | |
| 15 | Z243 | Key lock plate | | |
| 16 | Z2000R | Chromed GIVI logo | | |

Vyberte požadovaný náhradní díl, cenu a dostupnost vám potvrdíme na info@motosp.cz.